Failure to tighten the various stem bolts correctly can lead to serious accidents. To check that the handlebar is
Ȯsnmz Ȯyfe.ublf ipme pguif iboemfcbshsjqt xjui cpui iboet‹

/

Never mount the seat post above its maximum allowable height, indicated by an engraving on the seat post, since this could break the seat post or the seat tube

**Bemoov brake adjustment and maintenance items:**

# IMPORTANT TECHNICAL DATA

Cmm pg u i f ufdiojdbm tqfdjÒdbujpot gps fbdi cjlf npefmdbo cf gpvoe po pvs x fctjuf x x xÒcf nppw/cjlftÒcf

To help you with the assembly and maintenance of your BEMOOV bike, we have provided the tightening torque values recommended when adjusting or mounting components. It is imperative to respect these values to avoid causing irreparable damage which may cause accidents while using the bike.

## LIMITS OF RESPONSIBILITIES

Ensure strict compliance with the conditions of use, assembly, maintenance, and upkeep provided for in this manual.

BEMOOV cannot be held liable for damages or injuries due to: