STEP 3 :

Slide the quick release (QR) into the wheel hub. Check that

G. ADJUSTING THE REFLECTORS

Bemoov brake adjustment and maintenance items:

BEMOOV